

Installation Instructions Addendum

NOTE:

When installing this coil as a replacement coil in an Air Handler or Cased Coil, the suction line tube on the coil must be repositioned to allow the tube to exit through the close-off plate on the Air Handler or Cased Coil.

Re-position the tube by un-brazing the joint in the 2 piece suction header, rotate the tube 145° so it is in the 12 o'clock position, then re-braze the joint.

