

WIRING DIAGRAM


SMALL PACKAGED HEAT PUMP- SINGLE PHASE

208/230 VOLT

60HZ

NOTES:

1. Disconnect all power before servicing.
2. For supply connections use copper conductors only.
3. Not suitable on systems that exceed 150V to ground.
4. For replacement wires use conductors suitable for 105° C.
5. On models w/no pressure switch, Yellow Jumper connects "Y" & "T1" on Defrost Board.
6. On models w/pressure switch, Yellow Jumper connects "Y" & "T1" on Defrost Board.
7. Couper le courant avant de faire letretien.
8. Employez uniquement des conducteurs en cuivre.
9. Ne convient pas aux installations de plus de 150V a la terre.



710555B
(Replaces 710555A)

10/07