

INSTALLATION INSTRUCTION

INSTALLATION INSTRUCTIONS FOR 555642 COIL GUARD USED WITH R4G* 150/180 UNITS

928B-0405



NOTICE TO INSTALLER WARNING!

Refrigerant tubing located behind panels this Accessory is mounted. Special attention must be given if pre-drilling of holes or using screws other than those provided are used. Failure to follow these instructions could result in serious injury or property damage and may void Warranty.

The Coil Guard is designed to prevent damage to the condenser coil of the unit. The following parts are required:

- 1 - Rear Coil Guard
- 1 - Hardware Package
 - 8 - #10-16 x 1/2 Screw
- 1 - Installation Instruction

Step 1:

Check for correct model number and number of parts above:

Step 2:

Take rear coil guard and center left to right with top flange of guard under top of unit.

Step 3:

Then secure with screws provided.

